



MID:COM E:COUNT

Operators Reference Guide

**Reference Guide for Operating the
MID:COM E:Count Electronic Register**

TABLE OF CONTENTS

TABLE OF CONTENTS	2
TABLE OF FIGURES	4
Section 1 - TECHNICAL SPECIFICATIONS	5
Electrical Requirements	5
Operating Environment	5
Enclosure	5
Environmental Testing	5
Interconnect	5
Metrological Sealing	5
Mounting	5
Inputs/Outputs	6
Pulse Input	6
Pulse Output	6
Powered Control Outputs	6
Analog Input	6
Communications	6
Calibration	6
Registration Capacity (Units)	6
Section 2 - LAYOUT	7
Special Note on Keyboard Entry	8
Section 3 - WIRING DIAGRAM	9
Section 4 - OPERATION	10
E:Count Overview and Theory of Operation	11
Meter Calibration and Temperature Compensation.....	11
Meter Calibration (Un-compensated).....	11
Temperature Compensation.....	12
Product Codes.....	14
Minimum Initial E:Count Configuration Settings	15
Section 5 - MODES	16
Delivery Mode	16
Delivery Menu.....	18
Delivery Menu Categories.....	20
PRCODE - Product Code	20
SHIFT - Shift Report	20
DRIVER - Driver Code	20
DISVOL - Volumes	21
CALTKT - Calibration Report	21
EXIT - Exit Delivery Menu	21

Setup Mode	22
Setup Categories.....	24
NEWCOD - Set Security Code	24
STAGE1 - Stage 1 (Fast Flow) Shutoff Volume	24
STAGE2 - Stage 2 (Slow Flow) Dwell Volume	24
TIME - System Time	24
DATE - System Date	24
SALE - Next Sequential Sale Number	24
TRUCK - Truck Number	25
EXIT - Exit Setup Mode	25
 Calibration Mode	 26
Calibration Menu	28
Calibration Menu Categories.....	30
PCODE - Product Code	30
DISVOL - Volumes	30
CALFAC - Calibration Factor	30
TEMP F - Temperature in Degrees Fahrenheit	30
TEMP C - Temperature in Degrees Celsius	31
TABLE - Table Value at Current Temperature	31
MRATIO - Meter Ratio	31
CMPTBL - Temperature Compensation Status	31
SERIAL - E:Count Serial Number	31
PRINTR - Printer Setup	32
COPIES - Thermal Printer Ticket Copies	32
TIMER - Timer Setup	32
EXIT - Exit Calibration Menu	32
 Program Mode	 33
 Power-Up	 34
 Section 6 - SAMPLE TICKETS	 35
 Section 7 - Appendices	 37
Appendix A - E:Count to Mid:Com 8000 Interface	37
Theory of Operation	37
Return on Investment	37
Valve Options	37
E:Count Menu Changes	39
 INDEX	 43
 VERSION HISTORY	 45

TABLE OF FIGURES

Figure 1.	E:Count LCD and Keyboard Layout.....	7
Figure 2.	E:Count Wiring Diagram.....	9
Figure 3.	E:Count Operation.....	10
Figure 4.	E:Count Delivery Process.....	16
Figure 5.	E:Count Delivery Menu.....	19
Figure 6.	E:Count Setup Mode.....	23
Figure 7.	E:Count Calibration Process.....	27
Figure 8.	E:Count Calibration Menu.....	29
Figure 9.	E:Count Program Mode.....	33
Figure 10.	E:Count Fuel Delivery Tickets.....	35
Figure 11.	E:Count Shift Report and Calibration Report.....	36
Figure 12.	E:Count Operation - E:Count Controlling Valves....	41
Figure 13.	E:Count Operation - 8000 Controlling Valves.....	42

Section 1 - TECHNICAL SPECIFICATIONS

Electrical Requirements

Operating Voltage: 10-30 VDC unregulated
Operating Current: Standby 275 mA
Up to 3 solenoids activated: 1 A additional each

Operating Environment

Outdoors exposed to elements
Temperature Range: -40°C to +60°C (-40°F to 140°F)
Humidity: 100% Condensing

Enclosure

Aluminum permanent mold casting with epoxy powder coat
Rating: IP-68 and NEMA-4
Silicone gasket for keyboard and cover seals
Calibration and Program Screws seal with BUNA 'O' Ring

Environmental Testing

Temperature Range: -40°C to +60°C (-40°F to 140°F)
Moisture Ingression: Fully submerged for 24 hours
Vibration: 3 Gs, 30 Hz, 2 axes, 72 hours
Shock: 4 foot drop to concrete, 3 axes, 5 times each

Interconnect

Up to 5 multi-pin circular plastic connectors
Sealed to IP-68 standards
Compensator Probe uses a 1/4" NPT compression fitting with thread sealant

Metrological Sealing

Drilled head screws for:
Calibration Switch
Program Switch
Enclosure Cover
Connectors Seal Plate
All Mounting Accessories

Mounting

Industry standard 'Veeder-Root' bolt circle with 1/4-20 threads
Adapters available to mount all currently available meters

Inputs/Outputs

Pulse Input

Internal: 100 pulse-per-revolution (ppr) dual channel quadrature encoder for rotational input from positive displacement meters

External: Single or dual channel input from meters with electrical output, 3 to 30 V signal

Pulse Output

Calibrated pulse output for remote counting or monitoring devices.

Raw encoder pulse output for connection to small volume piston provers.

Powered Control Outputs

Three (3) High-side 12 V drivers for use with solenoid valves and other ancillary devices.

Analog Input

One (1) 4 to 20 mA current loop for applications including tank gauging.

Communications

Four (4) RS-232 compliant serial ports for use with printers, external computing devices, etc.

Calibration

Prescale Factor (MRATIO) Range: 1 to 255

Calibration Factor Range: 0.0001 to 1.9999

Compensation Accuracy: Four (4) decimal places from lookup table


Registration Capacity (Units)

Delivery: -99999.9

Totalizer: 9999999.9

Section 2 - LAYOUT

Figure 1. E:Count LCD and Keyboard Layout



GALLONSLITRES	'GALLONS' or 'LITRES' indicates the current Volume Mode (US or Metric).
VOLUME CORRECTED TO 60F15C	Displayed whenever the Temperature Compensation is active. '60F' in Gallons Mode, '15C' in Liters mode.
DELIVER	Indicates <u>Delivery Mode</u> is active and will display until the Fuel Delivery Ticket prints.
PRESET	Indicates the Preset Volume is being changed.
PRODUCT	Indicates the Product Code is being changed.
SETUP	Displayed in the <u>Delivery Menu</u> and the <u>Calibration Menu</u> .
CALIBRATE	Indicates the Calibration Screw has been backed out - will display until the Calibration Screw is tightened.

Special Note on Keyboard Entry

The E:Count uses special technique called **PRESS & HOLD** for keyboard entry. This technique eases keyboard operation, especially when wearing gloves, in the absence of any audible or tactile feedback. Simply press a button and wait for the desired action.


Examples:

- For menus press & hold the mode key until the selection appears.
 - PRESS & HOLD **<START/STOP>** to enter that selection.
 - PRESS & HOLD **<START/STOP>** to exit the selection.
- To enter number PRESS & HOLD the **<RIGHT>** or **<LEFT>** arrow keys to select the digit to be changed. To change the number PRESS & HOLD the **<UP>** or **<DOWN>** arrow.
- To start a delivery PRESS & HOLD **<START/STOP>**.
- To enter a preset PRESS & HOLD **<PRESET>**.

Pressing and releasing a button may give results but it is only coincidental that the button was held long enough.


Section 3 - WIRING DIAGRAM

Figure 2. E:Count Wiring Diagram



Section 4 - OPERATION

Figure 3. E:Count Operation



E:Count Overview and Theory of Operation

Meter Calibration and Temperature Compensation

The MID:COM E:Count model MCR-05 is a general purpose electronic meter register for use with mechanical positive displacement meter with rotational output as well as other types of meters with electronic pulse outputs. In the case of a rotational output, the E:Count has an internal 100 pulse per revolution (ppr) quadrature encoder which converts the meter rotation to a pulse train. Meter calibration and optional temperature compensation techniques are all digital in nature and are explained below.

Meter Calibration (Un-compensated)

Meter calibration is a two step process. First a prescale factor called MRATIO must be determined and entered. This number is an integer value from 1 to 255 and only needs to be entered when the E:Count is initially installed.

This factor serves three purposes:

1. It allows the resulting calibration factor to remain just above or below unity which preserves the "1 part in 10,000" calibration resolution. For example, if there were 10 times too many pulses per unit volume the calibration factor would be near 0.1. This would result in the least significant digit of the calibration factor representing 1 part in 1000.
2. It allows for the elimination of mechanical adjusters and gear reductions which can add torque to the meter as well as wear out and slip.
3. It allow for a convenient way to change units of measure, such as gallons, liters, kilograms, etc.

This factor can be determined by trial and error or by contacting MID:COM with the following information:

1. Meter manufacturer.
2. Meter size.
3. Units of measure.

The second step in calibration, and only step after initial installation, is to determine the calibration factor with a prover or master meter. For initial installation a factor of 1.0000 should be used as a point of reference. Subsequently use the present factor.

E:Count Overview (continued)

With a factor near unity, the meter error as expressed by PROVER VOLUME/REGISTER VOLUME results in a percentage in which the error can be added or subtracted to the current calibration factor as needed.

Another way to view the factor is that the digits to the right of the decimal represent the following:

- First digit - tens of units/hundred units
- Second digit - units/hundred units
- Third digit - tenths of units/hundred units
- Fourth digit - hundredths of units/hundred units.

The calibration factor represents the value of each pulse as it is received by the E:Count. These are added to each other and the resultant sum is compared to the volume currently displayed. If the new rounded value is greater than the current displayed value the displayed value is adjusted accordingly.

Temperature Compensation

Temperature compensation is done by table lookup only. The E:Count is loaded with the appropriate API or ASTM table for the following products:

- PROPANE
- DIESEL/HEATING OIL
- GASOLINE
- LUBE OIL
- METHANOL
- ANHYDROUS AMMONIA
- JET-A FUEL

The tables are interpolated and extrapolated as necessary to have 1024 entries ranging from -40 to +62.4 degrees Celsius in 0.1 degree steps. As each pulse is received the temperature is sampled and the corresponding table entry for that temperature is multiplied by the calibration factor. The result is added, rounded and displayed as described above, but as a separate value.

E:Count Overview (continued)

Thus, there is always a running count of uncompensated AND compensated volumes. After the delivery these values can be toggled on the display to facilitate computations without the need to run BOTH compensated and uncompensated tests.

Both the current temperature and its associated table value can be displayed. If adjustment is necessary for the net volume, the temperature is adjusted up or down to obtain the table value necessary for the next test to be accurate.

It can occur that when an accurate test is obtained, the displayed temperature is not the same as the test thermometer temperature. There can always be small discrepancies since the temperature can vary during the delivery and the displayed temperature is what the product is at after the delivery.

However, if the difference is large the following needs to be considered:

1. The displayed temperature will always correspond to the correct table value.
2. The resulting calculations using that value will also always be correct.
3. The table in the E:Count may not be the same as the one being used for the test.
4. The product being tested is not exactly the same as what the table is intended for.

The fourth item is the most common source of error especially in the case of propane. In the summer months is quite common for refiners to blend in other products with higher or lower coefficients of expansion thus skewing the test.

There is no inherent problem with adjusting the temperature to make the test come out correctly, however if the product changes later on, the system may go out of tolerance. This situation has come up so often that it is necessary to emphasize that the compensator may be working as designed and consideration should be given to other factors affecting the test.

E:Count Overview (continued)

Product Codes

The E:Count is able to handle 99 different produce codes. Each product code defines:

1. Product identifier (i.e. PROPANE) which is printed on the delivery ticket.
2. Calibration factor for the product.
3. Compensator status (on/off) for the product.
4. Assigned compensator table for the product.
5. Preset valve second stage dwell.

The product code must be selected in Delivery Mode before a delivery is started and also before entering calibration mode. The product code cannot be changed while in Calibration Mode. All settings made in any mode are stored associated with the current product code.

Minimum Initial E:Count Configuration Settings

Steps for the end-user to setup an E:Count "out of the box"

1. Delivery Menu
 - a. Driver
 - b. Product Code

2. Setup Mode
 - a. Time
 - b. Date
 - c. Next Sale Number
 - d. Truck Number
 - e. Stage 1 Shutoff
 - f. Stage 2 Dwell

3. Calibration Menu
 - a. Printer (and Copies if using Thermal printer)
 - b. Product Code
 - c. Temperature Compensation Setting
 - d. Meter Ratio
 - e. Table Number
 - f. Calibration Factor (with Prover)
 - g. Serial Number

Section 5 - MODES

Delivery Mode

To enter Calibration Mode back out the **<CALIBRATION SCREW>**. **CALIBRT MODE** will be shown and the E:Count will enter Calibration Mode.


To enter Program Mode back out the **<PROGRAM SCREW>** and the E:Count will automatically enter Program Mode.

To Set the **Preset Volume** press **<PRESET>**. **PRESET** will be shown and allow the Preset Volume to be modified.

To **Begin a Delivery** press **<START/STOP>** and **DELIVR PRINT** will be shown. The Delivery Ticket Header will print, the E:Count will reset to **00000.0**, and the Security Valve will open allowing product to be dispensed.

To enter the Delivery Menu press **<MODE>** and **PRCODE** will be shown.

Figure 4. E:Count Delivery Process



Delivery Mode (continued)

1. Press **<PRESET>** to enable the **Preset** and set the **Preset Volume**.
 - a. Press the **<ARROW>** keys to modify the current **Preset Volume**.
 - b. Press the **<START/STOP>** key to save the **Preset Volume** and enable the **Preset** for the next delivery.
2. Press **<START/STOP>** to **Begin a Delivery** and **Open the Security Valve**.
 - a. If a ticket is in the printer **DELIVR PRINT** will be displayed, the **Fuel Delivery Ticket Header** will print, and **VALVES OPEN** will be displayed.
 - b. The **Security Valve** will open and the display elements will reset (all on followed by all off).
 - c. If no ticket is in the printer **INSERT TICKET** will be displayed - **the E:Count will not begin a delivery until a ticket is inserted into the printer.**
3. **Deliver Product.**
4. Press **<PRESET>** to enable another **Preset** and set a **Preset Volume for the next Delivery Segment**.
 - a. Press the **<ARROW>** keys to modify the **Preset Volume for the next Delivery Segment** .
 - b. Press the **<START/STOP>** key to save the **Preset Volume** and enable the next **Preset Volume for the next Delivery Segment**.
5. Press **<PRINT>** to finalize and end the delivery.
 - a. **VALVES CLOSED** will be shown and the **Fuel Delivery Ticket** will print.
 - b. The **Delivered Volume** will remain on the display.

Note: **<START/STOP>** functions as an **<EMERGENCY STOP>** button while product is flowing. After an **<EMERGENCY STOP>** the **Security Valve** will be closed and the **Fuel Delivery Report** will not print until **<START/STOP>** is pressed **again** to end the delivery.

Delivery Menu

Delivery Menu Categories

PRCODE
SHIFT
DRIVER
TOTAL
DISVOL
CALTKT
SETUP
EXIT

When entering the Delivery Menu the E:Count will display the current Delivery Menu Category.

To display the next Delivery Menu Category press **<MODE>**.

To view or modify the Delivery Menu Category press **<START/STOP>**.

To exit the Delivery Menu and return to Delivery Mode press and hold **<MODE>** to display **EXIT**, and then press **<START/STOP>**.


To enter Setup Mode:

1. Press and hold **<MODE>** until **SETUP** is displayed in the Delivery Menu
2. Press **<START/STOP>**
 - a. The E:Count will display **ENTER CODE**.
3. Enter the **Security Code** and press **<START/STOP>**.
 - a. If the **Security Code** is correct **OK** will be displayed and the E:Count will enter Setup Mode.
 - b. If the **Security Code** entered is NOT correct **NOGOOD** will be displayed and the E:Count will return to Delivery Mode.

Note: The factory default **Security Code** is 000000.

Delivery Menu (continued)

Figure 5. E:Count Delivery Menu



Delivery Menu (continued)

Delivery Menu Categories

PCODE - Product Code

Press **<START/STOP>** to set the current **Product Code**.
The **Product Code** is a 2-digit number from 00 to 99.
Use the **<ARROW>** keys to change the **Product Code**.
Press **<START/STOP>** to save the **Product Code** and return to Delivery Mode.

Note on Product Code:

Changing the **Product Code** affects all calibration data. The **Calibration Factor**, **Temperature Compensation Setting** (enabled or disabled), and the **Stage 2 Dwell** are all stored separately for each **Product Code**. Changing the **Product Code** will load the saved value for each of these variables.

SHIFT - Shift Report

Press **<START/STOP>** to print the current **Shift Report**.
The E:Count will display PRINT while printing the **Shift Report**.
The E:Count will return to Delivery Mode automatically when **Shift Report** printing is complete.

DRIVER - Driver Code

Press **<START/STOP>** to set the current **Driver** code.
The **Driver** code is a 4-digit number from 0000 to 9999.
Use the **<ARROW>** keys to change the **Driver** code.
Press **<START/STOP>** to save the **Driver** code and return to Delivery Mode.

TOTAL - Totalizer

Press **<START/STOP>** to display the Current Totalizer.
The **Net Totalizer** will be displayed if Temperature Compensation is enabled - OR - the **Gross Totalizer** will be displayed if temperature compensation is disabled.
The **Totalizer** display requires two screens to show all of the **Totalizer** data; initially only the right-most 5 digits and the tenths will be displayed.

To view the left **Totalizer** digits press the **<LEFT ARROW>**.
To view the right **Totalizer** digits press the **<RIGHT ARROW>**.
Press **<START/STOP>** to exit the **Totalizer** and return to Delivery Mode.

Delivery Menu (continued)

DISVOL - Volumes

Press **<START/STOP>** to display the **Gross Volume** or the **Net Volume** of the previous delivery.

Press **<UP>** to display the **Gross Volume**.

Press **<DOWN>** to display the **Net Volume**.

Press **<START/STOP>** to return to Delivery Mode.

CALTKT - Calibration Report

Press **<START/STOP>** to print the current **Calibration Report**. See the **Sample Tickets** at the end of this reference for a sample **Calibration Report**.

The E:Count will display PRINT while printing the **Calibration Report**.

The E:Count will return to Delivery Mode automatically when **Calibration Report** printing is complete.

SETUP - Enter Setup Mode

Press **<START/STOP>** to enter Setup Mode.

ENTER CODE and then **000000** will be displayed and the **Security Code** must be entered to continue.

Use the **<ARROW>** buttons to display the **Security Code**.

Press **<START/STOP>** to enter the **Security Code** and continue in Setup Mode.

If the **Security Code** entered is correct the E:Count will display **OK** and begin Setup Mode.

If the Security Code entered is incorrect the E:Count will display **NOGOOD** and return to Delivery Mode.

EXIT - Exit Delivery Menu

Press **<START/STOP>** to exit the Delivery Menu and return to Delivery Mode.

Setup Mode

Setup Categories:

NEWCOD
STAGE1
STAGE2
TIME
DATE
SALE
TRUCK
EXIT

When entering Setup Mode the E:Count will require the operator to enter the **Security Code** to continue. After a valid Security Code is entered the E:Count will display the first Setup Category.


To display the next Setup Category press **<MODE>**.

To view or modify the Setup Category press **<START/STOP>**.

To exit Setup Mode and return to Delivery Mode press and hold **<MODE>** until the E:Count displays **EXIT** and then press **<START/STOP>**.

Setup Mode (continued)

Figure 6. E:Count Setup Mode



Setup Mode (continued)

Setup Categories

NEWCOD - Set Security Code

Press **<START/STOP>** to set the **Security Code**.

The **Security Code** is 6 digits from 000000 to 999999.

Use the **<ARROW>** keys to change the **Security Code**.

Press **<START/STOP>** to save the **Security Code** and return to Setup Mode.

STAGE1 - Stage 1 (Fast Flow) Shutoff Volume

Press **<START/STOP>** to set the **Stage 1 Shutoff** Volume.

The **Stage 1 Shutoff** Volume is a whole number from 00 to 99.

Use the **<ARROW>** keys to change the **Stage 1 Shutoff**.

Press **<START/STOP>** to save the **Stage 1 Shutoff** and return to Setup Mode.

STAGE2 - Stage 2 (Slow Flow) Dwell Volume

Press **<START/STOP>** to set the **Stage 2 Dwell** Volume.

The **Stage 2 Dwell** Volume is tenths of units from 000.0 to 999.9.

Use the **<ARROW>** keys to change the **Stage 2 Dwell**.

Press **<START/STOP>** to save the **Stage 2 Dwell** and return to Setup Mode.

TIME - System Time

Press **<START/STOP>** to set the current **System Time**.

The **Time** will be displayed in 24 hour format HH.MM.

Use the **<ARROW>** keys to set the **System Time**.

Press **<START/STOP>** to save the **System Time** and return to Setup Mode.

DATE - System Date

Press **<START/STOP>** to set the current **System Date**.

The **Date** will be displayed in the format MM.DD.YY.

Use the **<ARROW>** keys to set the **System Date**.

Press **<START/STOP>** to save the **System Date** and return to Setup Mode.

SALE - Next Sequential Sale Number

Press **<START/STOP>** to set the **Next Sequential Sale Number**.

The **Next Sequential Sale Number** will be displayed.

Use the **<ARROW>** keys to set the **Next Sequential Sale Number**.

Press **<START/STOP>** to save the **Next Sequential Sale Number** and return to Setup Mode.

Setup Mode (continued)

TRUCK - Truck Number

Press **<START/STOP>** to set the **Truck Number**.

The **Truck Number** will be displayed.

Use the **<ARROW>** keys to set the **Truck Number**.

Press **<START/STOP>** to save the **Truck Number** and return to Setup Mode.

EXIT - Exit Setup Mode

Press **<START/STOP>** to exit Setup Mode and return to Delivery Mode.

Calibration Mode

To enter Calibration Mode in Delivery Mode back out the <CALIBRATION SCREW> - the E:Count will display **CALIBRT MODE** and enter Calibration Mode.

If the **Compensator** is turned **ON**, the VOLUME CORRECTED TO legend will display and the **Net Volume** will be displayed. If the **Compensator** is turned **OFF**, the VOLUME CORRECTED TO legend will **NOT** display and the **Gross Volume** will be displayed.

If **SETUP** is visible <MODE> may be pressed to access the Calibration Menu.

Security Valve Note: The security valve will be open while the E:Count is in Calibration Mode allowing the operator to directly control product flow.

Delivery Ticket Note: No delivery tickets will print while the E:Count is in Calibration Mode. At the completion of Calibration Mode (after the tightening of the <CALIBRATION SCREW>) the E:Count will print a **CALIBRATION REPORT**.

To exit Calibration Mode tighten the <CALIBRATION SCREW>. **PRINT** will be displayed, the E:Count will print a CALIBRATION REPORT, and return to Delivery Mode.


Printer Copies Note: Only the **THERMAL** printer allows the selection of the number of copies, all other printer types print only 1 copy per delivery.

Note on Calibration Data:

Set the **Product Code** before changing any calibration data. The **Calibration Factor**, **Compensation Setting** (enabled or disabled), and the **Stage 2 Dwell** are all stored separately for each **Product Code**. Changing the **Product Code** will load the saved value for each of these variables.

Calibration Mode (continued)

Figure 7. E:Count Calibration Process



Calibration Menu

Calibration Menu Categories:

DISVOL
CALFAC
TEMP F
TEMP C
TABLE
MRATIO
CMPTBL
SERIAL
PRINTR
COPIES
TIMER
PRCODE
EXIT

When entering the Calibration Menu the E:Count will display the current Calibration Menu Category.


To display the next Calibration Menu Category press **<MODE>**.

To view or modify the visible Calibration Menu Category press **<START/STOP>**.

To exit the Calibration Menu and return to Calibration Mode press and hold **<MODE>** until the E:Count displays **EXIT** and then press **<START/STOP>**.

Calibration Menu (continued)

Figure 8. E:Count Calibration Menu



Calibration Menu (continued)

TEMP C - Temperature in Degrees Celsius

Press **<START/STOP>** to display the **Current Temperature**.
The current **Temperature in Degrees Celsius** will be displayed (if the temperature probe is installed).
Press **<UP>** or **<DOWN>** to change the probe temperature.
Press **<START/STOP>** to save the temperature and return to the Calibration Menu.

TABLE - Table Value at Current Temperature

Press **<START/STOP>** to display the current value in the compensation table based on the current temperature.
Press **<START/STOP>** to return to the Calibration Menu.

MRATIO - Meter Ratio

Press **<START/STOP>** to enter the **Meter Ratio**.
Use the **<ARROW>** buttons to set the **Meter Ratio**.
Press **<START/STOP>** to save the **Meter Ratio** and return to the Calibration Menu.

Note: Contact the MID:COM factory or your distributor for more information about meter ratios and suggested values.

CMPTBL - Temperature Compensation Status

Press **<START/STOP>** to display the **Temperature Compensation Status**.
Press the **<UP ARROW>** to set **Temperature Compensation ON**.
Press the **<DOWN ARROW>** to set **Temperature Compensation OFF**.
Press **<START/STOP>** to save the **Temperature Compensation Status** and return to the Calibration Menu.

SERIAL - E:Count Serial Number

Press **<START/STOP>** to set the **E:Count Serial Number**.
The current **E:Count Serial Number** will be displayed.
This is intended to allow a circuit board in the E:Count to be replaced and set the **E:Count Serial Number** to match the Faceplate of the E:Count.
Use the **<ARROW>** buttons to set the **E:Count Serial Number**.
Press **<START/STOP>** to save the **E:Count Serial Number** and return to the Calibration Menu.

Calibration Menu (continued)

PRINTR - Printer Setup

Press **<START/STOP>** to display the **Printer Type**.

Press the **<DOWN ARROW>** to cycle through the **Printer Types**:

MIDCOM

EPSON

THERMAL

NO PRINTER

Press **<START/STOP>** to save the **Printer Type** and return to the Calibration Menu.

COPIES - Thermal Printer Ticket Copies

Press **<START/STOP>** to display the **Number of Thermal Copies**.

Press the **<UP ARROW>** to increase the number **Copies**.

Press the **<DOWN ARROW>** to decrease the number of **Copies**.

Press **<START/STOP>** to save the **Number of Thermal Copies** and return to the Calibration Menu.

TIMER - Timer Setup

Press **<START/STOP>** to display the **Timer Status**.

Press the **<UP ARROW>** to set the **Timer ON**.

Press the **<DOWN ARROW>** to set **Timer OFF**.

Press **<START/STOP>** to save the **Timer Status** and return to the Calibration Menu.

EXIT - Exit Calibration Menu

Press **<START/STOP>** to exit the Calibration Menu and return to Calibration Mode.


Program Mode

To enter Program Mode in Delivery Mode back out the <**PROGRAM SCREW**> - the E:Count display will not change however the E:Count will be in Program Mode.

Proceed as directed by MID:COM personnel to complete E:Count programming.

To exit Program Mode (after programming is complete) tighten the <**PROGRAM SCREW**> - the E:Count will reset and will be in Delivery Mode.

Figure 9. E:Count Program Mode



Power-Up

On Power-up the E:Count will:

1. Perform a set of diagnostic tests
2. Display the User Software Version: U ##
3. Display the Metrological Software Version: M ##
4. Reset all display elements
5. Enter Delivery Mode and display the previous quantity.

Section 6 - SAMPLE TICKETS

Figure 10. E:Count Fuel Delivery Tickets

INSERT FACE UP <small>MIDWEST COMPUTER REGISTER CORP. - HAMILTON, IOWA 50401</small>	INSERT FACE UP <small>MIDWEST COMPUTER REGISTER CORP. - HAMILTON, IOWA 50401</small>
<p style="text-align: center; font-weight: bold; font-size: 1.2em;">MID:COM E:Count</p> <p style="text-align: center;">FUEL DELIVERY TICKET</p> <p>TRUCK# 0001 DRIVER# 0001 DATE 03/15/06 STIME 12:59 DATE 03/15/06 FTIME 13:00</p> <p>SALE# 000005</p> <p>GALLONS START 0.0 GALLONS FINISH 00042.1</p> <p>PRODUCT # 01 PRODUCT PROPANE</p> <p>VOLUME COMPENSATED TO 60F COMP. TABLE # 01</p> <p>TOTALIZER 0000129.2 METER # 000000</p> <p style="font-size: 0.8em; margin-top: 20px;">FORM MID:COM SPECIAL</p>	<p style="text-align: center; font-weight: bold; font-size: 1.2em;">MID:COM E:Count</p> <p style="text-align: center;">FUEL DELIVERY TICKET</p> <p>TRUCK# 0001 DRIVER# 0001 DATE 03/15/06 STIME 12:57 DATE 03/15/06 FTIME 12:59</p> <p>SALE# 000004</p> <p>GALLONS START 0.0 GALLONS FINISH 00047.1</p> <p>PRODUCT # 01 PRODUCT PROPANE</p> <p>VOLUME COMPENSATED TO 60F COMP. TABLE # 01</p> <p>TOTALIZER 0000087.1 METER # 000000</p> <p style="font-size: 0.8em; margin-top: 20px;">FORM MID:COM SPECIAL</p>

Figure 11. E:Count Shift Report and Calibration Report

<p>INSERT FACE UP</p> <p>MIDWEST COMPUTER REGISTER CORP. - HAMPTON, IOWA 50401</p>	<p>INSERT FACE UP</p> <p>MIDWEST COMPUTER REGISTER CORP. - HAMPTON, IOWA 50401</p>
<p style="text-align: center;">MID:COM E:Count</p> <p style="text-align: center;">SHIFT REPORT</p> <p>TRUCK# 0001 DRIVER# 0001 DATE 03/14/06 STIME 15:32 DATE 03/15/06 FTIME 13:01</p> <p>TOTALIZER 0000129.2 METER # 000000 PROD 01 NET 0000129.2 PROD 01 GROSS 0000131.5</p> <p style="text-align: center;">END SHIFT REPORT</p> <p style="text-align: left; font-size: small;">FORM 882 COM SPECIAL</p>	<p style="text-align: center;">MID:COM E:Count</p> <p style="text-align: center;">CALIBRATION REPORT</p> <p>TRUCK# 0001 DRIVER# 0001 DATE 03/15/06 STIME 12:59 TOTALIZER 0000129.2</p> <p>USER SOFTWARE VER. VE103A METROLOGICAL VER. MOD10A METER # 000000</p> <p>ADJUSTMENT EVENT # 000002 CONFIGURE EVENT # 000002</p> <p>PRODUCT # 01 PRODUCT PROPANE METER RATIO 10 CALIBRATION FACTOR 1.0000 COMPENSATOR STATUS ON COMP. TABLE # 01 VOLUME COMPENSATED TO 60F</p> <p style="text-align: center;">----- INSPECTOR</p> <p style="text-align: left; font-size: small;">FORM 882 COM SPECIAL</p>

Section 7 - Appendices

Appendix A - E:Count to Mid:Com 8000 Interface

Theory of Operation

The MID:COM 8000 is the ultimate, rugged, easy to use cab mounted computer, printer, and data transfer system. Using the SD Data Card the driver has access to 50,000 complete customer records. An easy-to-follow menu guides the driver through the delivery process. The most popular software providers offer a MID:COM SD Card interface that provides automatic posting from the SD Card to your accounts receivable accounting package.

The MID:COM 8000 Cab-Mounted Computer has a seamless interface with the MID:COM E:Count Electronic Register. The combination of these systems allows fuel distributors to utilize the most cost-effective, flexible, efficient, secure, and reliable vehicle-based electronic registration system on the market today.

Return on Investment

Electronic Temperature Compensation:

- Reduces shrinkage by 1%
- Increases driver efficiency by 10% to 15%
- Reduces meter maintenance by 50%
- Eliminates handwritten tickets and ticket notation errors
- Reduces ticket posting time and eliminates posting errors
- Eliminates postage costs

Valve Options

When the MID:COM E:Count Electronic Register is connected to a MID:COM 8000 Electronic Computer either the E:Count or the 8000 can control the security valves.

The Calibration must be performed on the MID:COM E:Count regardless of the Valve Control Setting.

Appendix A - E:Count to Mid:Com 8000 Interface (continued)

MID:COM 8000 controls the valves:

1. The Preset Gallons and Preset Dollars fields from the SD Card fields allow the 8000 to control the Preset.
2. The 8000 will automatically shut the valves when the necessary quantity (based on dollars or gallons) has been reached.
3. The driver may enter the Preset Gallons or Preset Dollars on the 8000 directly.
4. Once the Preset has been reached there is no way to continue the current delivery or enter a new preset - a new delivery (meaning a new ticket) must be started.
5. Operation - the Operator may:
 - a. Set the Preset Amount on the 8000 using the 'Preset' option or the 'Preset' amount from the SD-Card.
 - b. Begin and End the delivery process on the 8000 using the **<DOWN>** and **<START/STOP>** buttons respectively
 - c. End the delivery and print the delivery ticket by pressing **<PRINT>** on the E:Count in 'Remote Print' applications.

MID:COM E:Count controls the valves:

1. The driver manually enters the Preset Quantity on the E:Count.
2. The E:Count will automatically shut the valves when the Preset Quantity has been reached.
3. If necessary the driver has the ability to restart the delivery after the Preset has been reached and continue the current delivery.
4. If necessary the driver has the ability to enter a new Preset Quantity and continue the delivery to the new Preset Quantity. In addition the driver may repeat this process as many times as necessary.
5. Operation - the Operator may:
 - a. Set the Preset Amount on the E:Count using the **<PRESET>** button.
 - b. Begin and End the delivery process on the E:Count using the **<START/STOP>** and **<PRINT>** buttons respectively
 - c. End the delivery and print the delivery ticket by pressing **any button** on the 8000.
 - d. Compute and add a discount by pressing **<DISC>** on the 8000.

Appendix A - E:Count to MID:COM 8000 Interface (continued)

E:Count Menu Changes

1. Delivery Menu

a. Valve Controlled by E:Count

i. No Ticket in the 8000

1. TOTAL

NOTE: The Totalizer is the only option available when the E:Count is controlling the Valves and there is no ticket in the printer.

ii. Ticket in the 8000

1. PRCODE

2. DISVOL

3. SETUP

4. EXIT

b. Valve controlled by 8000

- i. No menu available - all E:Count buttons disabled

2. Setup Menu

a. Valve Controlled by E:Count (NOTE: The Setup Menu is available in the Delivery Menu only when a ticket is in the 8000)

i. NEWCOD

ii. STAGE1

iii. STAGE2

iv. TIME

v. DATE

vi. EXIT

b. Valve controlled by 8000

- i. No menu available - all E:Count buttons disabled

Appendix A - E:Count to MID:COM 8000 Interface (continued)

E:Count Menu Changes (continued)

3. Calibration Menu

a. Valve Controlled by E:Count **or** 8000

- i. PRCODE
- ii. DISVOL
- iii. CALFAC
- iv. TEMP F
- v. TEMP C
- vi. TABLE
- vii. MRATIO
- viii. CMPTBL
- ix. SERIAL
- x. TIMER
- xi. V CTRL**

1. Available only with the E:Count 8000 Interface


2. Select the "Valve Control" setting

- a. E:Count: The E:Count controls the security valves as explained above.
- b. 8000: The 8000 controls the security valves as explained above.

- xii. EXIT


Appendix A - E:Count to MID:COM 8000 Interface (continued)

Figure 12. E:Count Operation - E:Count Controlling Valves



Appendix A - E:Count to MID:COM 8000 Interface (continued)

Figure 13. E:Count Operation - 8000 Controlling Valves



INDEX

Analog Input.....	6	Operating Current.....	5
Calibration		Operating Environment.....	5
Factor.....	6, 11, 12, 15, 20, 26, 30	Operating Voltage.....	5
Factor Range.....	6	Powered Control Outputs.....	6
Menu.....	7, 15, 26, 28, 29, 30, 31, 32	Power-Up.....	34
Mode.....	16, 26, 27, 28, 32	Prescale Factor Range.....	6
Report.....	20, 21, 26	Preset Volume.....	7, 16, 17
Screw.....	7, 16, 26	Printer	
Calibration Report.....	36	Type	
Communications.....	6	Thermal.....	26
Compensation		Printer.....	15, 17
Accuracy.....	6	Copies.....	26
Table.....	31	Printer	
Copies.....	15, 26, 32, <i>See Printer</i>	Type	
Date.....	15	MIDCOM.....	32
Delivery		Printer	
Menu.....	7, 15, 16, 18, 19, 20, 21	Type	
Mode.....	7, 17, 18, 20, 21, 22, 25, 26, 30, 33, 34	Thermal.....	32
Delivery Ticket.....	7, 16, 17, 26	Printer	
Driver Code.....	15, 20	Type	
E		NO PRINTER.....	32
Count to MID		Printer	
COM 8000 Interface ..	37, 38, 39, 40, 41, 42	Thermal Printer Ticket	
Electrical Requirements.....	5	Copies.....	32
Emergency Stop.....	17	Printer Type.....	32
Enclosure.....	5	Product Code.....	7, 15, 20, 26, 30
Enclosure Rating.....	5	Program Mode.....	16, 33
Environmental Testing.....	5	Program Screw.....	16, 33
Faceplate.....	31	Pulse Input.....	6
Firmware Version.... <i>See Software</i>		Pulse Output.....	6
Version		Registration Capacity.....	6
Fuel Delivery Ticket.....	35	Sale Number.....	15, 24
Humidity.....	5	SD Card.....	37, 38
Inputs/Outputs.....	6	SD Data Card.....	37
Interconnect.....	5	Security Code.....	18, 21, 22, 24
Meter Ratio.....	15, 31	Security Valve.....	16, 17, 26
MID		Serial Number.....	15, 31
COM 8000.....	37	Setup Mode.....	15, 18, 21, 22, 23, 24, 25
Moisture Ingression.....	5	Shift Report.....	36
Mounting.....	5	Shock.....	5
		Software Version	
		Metrological.....	34

User.....	34	Temperature Range.....	5
Stage 1 Shutoff.....	15, 24	Time.....	15
Stage 2 Dwell.....	15, 20, 24, 26, 30	Totalizer.....	6, 20
System Date.....	24	Gross.....	20
System Time.....	24	Net.....	20
Temperature		Truck Number.....	15, 25
Celsius.....	31	Valve Control.....	40
Current.....	30, 31	Vibration.....	5
Fahrenheit.....	30	Volume	
Temperature Compensation....	7, 20,	Gross.....	21, 26, 30
31, 32		Net.....	21, 26, 30
Temperature Compensation			
Setting.....	15		

VERSION HISTORY

<u>Version</u>	<u>Date</u>	<u>Author</u>	<u>Description</u>
1.01	09-27-05	BJS	Document created
1.02	02-28-06	BJS	Updated menus
1.03	03-06-06	BJS	Updated menus
1.04	03-15-06	BJS	Updated descriptions, added images
1.05	03-16-06	BJS	Added E:Count to 8000 Interface
1.06	03-20-06	BJS	Updated Images